

WearFlex



Exact mixing of Densit® WearFlex™ is required before application.

WearFlex



Densit® WearFlex™ 2000
being installed in a cyclone.

WEARFLEX



Classifier Cone being lined with
Densit® WearFlex™ 2000.

WEARFLEX



Densit® WearFlex™ 2000 being installed.

WEARFLEX

Densit® WearFlex™ 2000 being installed in the upper section of a Cyclone.

WEARFLEX

A stainless steel cone lined with Densit®
WearFlex™ 2000 is ready to be shipped.

WEAR FLEX



One of twenty eight separate chute components lined with Densit® WearFlex™ 2000.

WEAR FLEX

A riffle housing lined with Densit® WearFlex™ 2000.